# IN-LINE ILLUMINATION

#### **FUNDAMENTALS**

In-line illumination is a unique style of lighting that incorporates the illumination into the optical train of the machine vision lens, usually by means of a fiber optic light guide or LED light source and a beam splitting optic. Although in-line illumination is not as bulky as diffuse axial illumination, and may be easier to integrate into a system that has tight space constraints, there are important optical differences a system designer must consider. In-line illumination is much more directional when compared to diffuse axial lighting, which, due to the chief rays being nearly parallel to the optical axis in object space, is one of the reasons that in-line illumination is widely incorporated with telecentric lenses (*Figure 1*). In comparison, diffuse axial lighting will project the illumination at a multitude of different angles, displaying different properties on the object and image planes.

Vastly different results will also come from comparing in-line illumination to brightfield illumination. *Figure 2* shows a chrome on glass, positive USAF 1951 contrast target illuminated both with brightfield illumination and with in-line illumination.

The most immediate difference between the two types of illumination is the complete contrast reversal between the two images. Additionally, the defects in the target are more readily apparent in the brightfield image, which, depending upon the application, can be either a positive or a negative effect. Interestingly, the highly reflective nature of the target yields about 10% better contrast for the in-line image when compared to the brightfield image – the reason for this is explained below.

> Go to WWW.EDMUNDOPTICS.EU/IMAGING-LAB to become an Imaging Expert.




Figure 1: Diagram of in-line illumination within a telecentric lens.




Figure 2: Chrome on glass USAF 1951 resolution target with brightfield illumination (Figure 2a), and inline illumination (Figure 2b).



www.edmundoptics.eu/illumination

#### NEED HELP? Contact Us Now!

UK:	+44 (0) 1904 788600	GERMANY:	+49 (0) 721 6273730
sales@edmundoptics.eu		FRANCE:	+33 (0) 8 20 20 75 55

## WHEN TO USE IN-LINE ILLUMINATION

When considering using in-line illumination, it is important to understand exactly where it is applicable and where it is not. In-line illumination is ideal for the inspection of specular or semi-specular objects, such as semiconductor wafers or CCDs, due to the nature of the rays on the illumination path. Using two different telecentric lenses, one with in-line illumination and one without, images of the same CCD demonstrate the differences between brightfield illumination (using a ring light) and in-line illumination. The images are shown in Figure 3, the main differences are summarized in Table 1. In-line illumination would be a better choice to inspect the wires along the edge of the CCD due to the higher, more even contrast between the wires and the rest of the CCD. As shown in Figure 4, the reason that the wires in Figure 3 appear bright using brightfield illumination and dark using in-line illumination is due to the ray paths of the lighting. With brightfield illumination, the rays are scattered into the lens, and with in-line illumination, the rays are scattered away from the lens.

With brightfield illumination, the rays originating from the ring light are reflected by the object into the lens. The reflections will vary based on the angle of the individual sources in the ring light as well as the angle of the wires themselves with respect to the CCD surface and the solder material at the tips, which is why the reflections have non-uniform pixel values along the length of the wire. Using in-line illumination, all of the rays are reflected by the object and scattered away from the lens such that none of the light that hits the wires is reflected back into the lens and onto the sensor. The more even contrast of the background, along with the stronger contrast of the wires, makes in-line illumination a better choice for the inspection of the wires than brightfield illumination. If the CCD cover glass were to be inspected for digs or chips, in-line illumination would also be the more advantageous choice since the overall image has a much more even contrast. The dark chips shown using in-line illumination (a result of the light being scattered as shown in Figure 4) would appear at a much higher contrast to the busy CCD background than the chips shown in the high contrast image formed using a brightfield system, as demonstrated in Figure 3.




Figure 3: Comparison of Brightfield Illumination (left) with In-line Illumination (right).

Brightfield Illumination	In-line Illumination
Low Contrast Wires	High Contrast Wires
Bright Chip on Faceplate	Dark Chip on Faceplate
High Contrast Image	Even Illumination with Consistent Contrast between Features (red square)

Table 1: Comparison of Brightfield and In-Line Illumination




Figure 4: Comparison of Ray Paths Using Brightfield Illumination (left) and In-line Illumination (right).

## WHEN NOT TO USE IN-LINE ILLUMINATION

Due to its multiple advantages, it is often believed that in-line illumination is always the superior choice for space-constrained systems. Unfortunately, it is not the best solution for objects that are optically diffuse or for objects requiring a large field of view. When used with diffuse objects, in-line illumination produces a hotspot on the image caused by the Lambertian (a nearly constant bidirectional reflectance distribution function) tendencies of the object, which is detrimental to any inspection system. *Figure 5* shows an image of a diffuse object of wooden material both with (right image) and without (left image) in-line illumination.

When the primarily Lambertian object is in-line illuminated, the image has a well-defined hotspot in the center of the field of view. This hotspot effectively washes out the desired contrast, yielding a contrast of about 70% for the brightfield image, and about 8% for the in-line illuminated image, with both contrast values taken at the center of the image.

There are, of course, other situations where in-line illumination is not the ideal option. When a large field of view is required, the étendue of the illumination system becomes a problem, in that spreading out the flux of the light over a large field inherently leads to a much less dense bundle of photons, and therefore has a negative impact on the throughput of the system as a whole. Imperfect light sources also significantly and negatively impact the performance of inline illumination systems with large fields of view, as the small imperfections are bolstered over the large projection in the object plane.




Figure 5: Comparison of wooden object with brightfield illumination (left) and in-line illumination (right).



#### NEED HELP? Contact Us Now!

UK:	+44 (0) 1904 788600	GERMANY:	+49 (0) 721 6273730
sales@edmundoptics.eu		FRANCE:	+33 (0) 8 20 20 75 55

www.edmundoptics.eu/illumination